MAINTENANCE OF YOUR OIL-TREATED PRODUCT

REPLENISHMENT

STEP 1

Clean the surface with a mild soapy water solution. Wipe the surface dry.

STEP 2

Apply a neutral or white pigmented furniture oil with a soft cloth. Excess oil must be removed 30 minutes after application.

STEP 3

Polish with a clean cloth until an even look is attained. The oil will not harden until after 12 hours. Do not cover any of the surface until the oil has hardened.

IMPORTANT

Cloths with oil should be disposed of in an airtight bag with a little water as they can be highly flammable.

RE-TREATMENT IN CASE OF EXTRA WEAR

STEP 1

Clean the surface with a mild soapy water solution. Wipe the surface dry.

STEP 2

Sand the surface lightly with 220-280 grit sandpaper until an even surface is attained. Important note: Sand along the grains of the wood. Clean the surface with a wet cloth.

STEP 3

Layer 1: Apply a neutral or white-pigmented furniture oil (depending on your furniture) with a soft cloth – wait approximately 30 minutes.

Layer 2: Apply yet another layer on top of the wet oil so the surface appears glossy for another 30 minutes.

STEP 4

Remove excess oil no later than 30 minutes after the application of the last layer (bringing the length of the oil treatment to a total of 60 minutes before wiping off).

STEP 5

Polish with a clean cloth until an even look is attained. The oil will not harden until after 12 hours. Do not cover any of the surface until the oil has hardened.

IMPORTANT

Cloths with oil should be disposed of in an airtight bag with a little water as they can be highly flammable.