

&tradition

Smoked oil kit

Directions of use:

Note: it is recommended to test the oil on a non-visible surface before oiling the entire piece of furniture.

1. Ensure that the furniture is clean and completely dry before oiling.
2. Sand the furniture to ensure an even and uniform surface. Always sand in the direction of the wood structure.
3. Shake the bottle well.
4. Apply an even and thin layer of the oil using a soft sponge. Do not leave wet pools of oil on the surface of the furniture.
5. Let the oil sink into the wood for approximately 20 minutes and then carefully remove excess oil using a dry dust free cloth or a soft sponge.
6. Let the furniture dry for a couple of hours and polish lightly with a dry dust-free cloth.
7. To avoid staining from the furniture, let the furniture dry at least 8 hours and polish again with a dry dust-free cloth before taking the furniture into use.
8. The treatment can be repeated if a more intense color is desired.

Safety: Keep out of reach of children. Further information about the oil can be found in the safety data sheet on: www.andtradition.com / Download / User manuals

Disposal: The oil must not be disposed of in the drain. The oil should be disposed according to national rules and regulations.

Please note: The oil is intended for use only on &tradition smoked oiled oak furniture. Oiling is at own risk.