

MATERIALS AND CLEANING

INDOOR COLLECTION

The indoor furniture consists of two parts; an inner beanbag and a removable cover. The outer cover comes in three different fabric varieties. In the catalog, you can see which models come in which fabrics. The idea of dividing the product into FILLING + INNER BAG + OUTER COVER is to make the product more long-lasting, as the outer cover can easily be replaced or washed as needed. All materials can thus be recycled or repaired independently of each other. In addition, the inner beanbag can also be refilled if it becomes flat over time or you can reuse the filling for another product.

OUTDOOR

TRIMM's furniture is made from SUNBRELLA PLUS[®] which is a performance material, originally designed for boats. Therefore SUNBRELLA PLUS[®] is extremely waterproof, thanks to the acrylic coating on the backside (It is three times more water repellent than any other outdoor materials from Sunbrella). At the same time, SUNBRELLA PLUS[®] is breathable, which prevents condensation and moist. It has maximal resistance against mold because the acrylic coating contains a special fungus killing mixture of saltwater.

SUNBRELLA PLUS[®] is also UV resistant and the color fastness is an 8 on a scale from 1-10, where 10 is the best.

The material doesn't need any other maintenance than simple cleaning. It is very easy to maintain, and most stains can be removed with water and mild soap. For more stubborn stains, bleach can be used, without fear of damaging the fabric or removing the color. One of the best ways to keep the fabric nice is to keep of the deep cleaning by maintaining the fabric correctly. This can be done by brushing off the dirt, before it soaks in, and wipe off stains when they happen.

NOTE: When receiving your new outdoor products, you might experience light marks on the fabric surface. This is residue from the back coating of the fabric and is a part of the overall expression of the furniture. It will however fade out and disappear over time and when used regularly.



All products are produced in the EU

GENERAL INFORMATION

General Cleaning Instructions

- First, brush off loose dirt.
- Hose down fabric thoroughly. Water should be cold to lukewarm and never more than 100°F/38°C.
- Prepare a cleaning solution of water and mild soap such (no detergents).
- Use a soft bristle brush to clean. Allow cleaning solution to soak into the fabric.
- Be sure to rinse thoroughly to remove all soap residue.
- Allow Sunbrella to air dry only. Never apply heat to Sunbrella fabrics.

Deep or Stubborn Stain Cleaning

If stubborn stains or mildew persist, you can use a diluted chlorine bleach/soap mixture for spot cleaning of mildew or other similar stains. Protect the area around the Sunbrella fabric when using a bleach solution – bleach may discolor non-Sunbrella fabrics. Always rinse Sunbrella thoroughly in order to completely remove bleach.

HAND WASH: Mix 4 ounces (1/2 cup) chlorine bleach with ¼ cup of mild soap and one gallon of water. Clean with a soft bristle brush. Allow mixture to soak into the fabric for up to 15 minutes. Rinse thoroughly until all soap residue is removed. Allow airing dry. Repeat if necessary.

FAQ

Can I leave my TRIMM product outside?

Yes, all outdoor products are designed and made in SUNBRELLA PLUS® or Sunbrella In&Out® for outside use. The products will always remain nicer for a longer time if you do not leave them out for a longer period of time, but they are designed to withstand all weather conditions.

The products which are not clearly declared as outdoor products, should not be used outside. This means the entire indoor collection in the following materials; Recycled NOAH, Teddy, Wool, and Leather.

The filling of my TRIMM product decrease. Is this normal?

We use the best EPS beads available, and they have a high density. But it's normal that the filling will compress over time with use.

Does my TRIMM product have a separate inner bag?

All cushions have a separate inner bag, as well as the beanbags in following product lines; Teddy Collection, Wool Collection, Recycled NOAH Collection.

How can I refill my TRIMM product?

1. Take your TRIMM product and turn the bottom upside, open the Velcro and pull the small fabric tube out. In the indoor products, you will find this in the inner bag.
- 2) At the end of the fabric tube, there is a zipper. Open the zipper.
- 3) If you are filling with a refill, insert the plastic bag opening into the fabric tube opening. You can close the zipper to connect the two openings better and thus prevent leakage.
- 4) It's a good idea to be two people to fill. One can hold the opening of the fabric tube on the product while the other person is filling the beads in.

Voilà! Enjoy your brand new TRIMM product!

How can I wash my TRIMM product?

To see cleaning instructions, please see the cleaning/maintenance tab under each product.

There is a tear in my TRIMM product, how can I fix it?

If you want to order a repair kit, please order via: am@trimm.dk

Caution

BURN: Keep your products far from any direct source of heat: fire, candles, lighter.

CUTOFF: Avoid hooking your TRIMM Copenhagen with pointed or sharp objects. Pay attention to the edges of tables or door handles.

EXCESS WATER: The Outdoor Collection is not meant to be immersed in a pool or ocean.